

User manual

Hoof trimming crush

SA0051/SA0051B



Manufacturer:

Wopa Constructiebedrijf BV
Rector Hulshofstraat 10
7135 JV Harreveld
The Netherlands

☎: +31-(0)544 372415
💻: +31-(0)544 372445
Email: info@wopa.com
Website: www.wopa.com

© Copyright 2026

No part of this publication may be reproduced, stored in a search system or transferred in any form whatsoever, either electronically or mechanically, or by photocopying or recording, or in any other way whatsoever without prior written consent from Wopa Constructiebedrijf BV (hereinafter in this manual also referred to as "Wopa").

Introduction

Wopa Constructiebedrijf BV specialises in development and manufacture of hoof trimming and treatment crushes for cows and bulls for professional users as well as for cattle farmers.

Our crushes are developed and manufactured in the highest possible quality, according to the strictest requirements as far as safety, user convenience, animal welfare and hygiene are concerned, always striving for an optimum.

This manual contains information and instructions relevant to installation, operation and maintenance of the machine.



- The machine is not suitable for use in explosive hazardous environments.
- All persons responsible for operation must, at minimum, read and comprehend the sections on operation and safety of these operating instructions.
- All persons responsible for assembly, installation, maintenance and/or repair must read and comprehend all these operating instructions.
- The user is responsible for interpretation and use of this manual under all conditions. Should you have any doubts or questions regarding the correct interpretation, please contact the owner or the supervisor.
- Keep this manual nearby the installation and within the users' reach.
- Keep a log of all major maintenance work, adaptations to the installations and observations, see Annex 8.1.
- Changes to the installation/machine are not permitted without prior written approval from the supplier.
- Contact the supplier for any special maintenance work not included in this manual.
- Comply with the safety requirements as given in Section 3 at all times.
- Proper functioning as well as the safety of the system can only be guaranteed if the recommended maintenance is carried out correctly and on time.

Manufacturer/Supplier: WOPA Constructiebedrijf BV
Address: Rector Hulshofstraat 10
Postal code/Town: NL-7135 JV Harreveld
Telephone: +31(0)544 372415
E-Mail: info@wopa.com

Machine name: Claw treatment crush
Year of construction: 2026
Type number: SA0051BHL
Serial number: xxx

WOPA

Rector Hulshofstraat 10
NL-7135 JV Harreveld
The Netherlands

www.wopa.com
info@wopa.com
Tel: +31 544 37 24 15

CE
UK
CA

Type	SA0051BHL	Machine	Claw Treatment Crush			
Serial no.	1028	Watts	400	kW	Hz	50
Total weight	1022 kg	Voltage		V	Year	 2026



Warranty

The warranty is subject to the following limitations. The warranty period for products supplied by Wopa is 12 months from the date on the purchasing document. The warranty is limited to production and material errors and therefore does not cover any breakdowns due to a part of the product exposed to any type of wear. Normal wear as can be expected from using this product is therefore excluded.

1. Wopa's responsibility remains limited to replacing defective parts; we recognise no claims to any other type of loss or costs.
2. The warranty is automatically void in case of overdue or poorly implemented maintenance.
3. Should you have any doubts regarding maintenance work or should the machine fail to operate correctly, contact the supplier.
4. The warranty does not apply if the defect is the result of incorrect or negligent use or of maintenance carried out contrary to the instructions in this manual.
5. The warranty is void if any repairs or adaptations are made to the product by third parties.
6. Defects ensuing from damage or accidents caused by external factors are excluded from the warranty.
7. If we replace any parts in accordance with the obligations ensuing from this warranty, the parts we replaced become our property.

Table of Contents

INTRODUCTION	3
WARRANTY	5
TABLE OF CONTENTS	6
EC- DECLARATION OF CONFIRMITY FOR MACHINERY (COPY)	8
OVERVIEW OF SYMBOLS	9
PICTOGRAMS	10
1. TECHNICAL INFORMATION	11
2. DESCRIPTION OF THE INSTALLATION	13
2.1. DESCRIPTION OF THE MAIN COMPONENTS SA0051/SA0051B	13
2.2. ELECTRICAL INSTALLATION	15
2.3. HYDRAULIC INSTALLATION	17
3. SAFETY	20
3.1. GENERAL	20
3.2. DURING NORMAL USE	21
3.3. OPERATING PERSONNEL	21
4. INSTALLATION	22
4.1. LOCATION	22
4.2. CONNECT THE MACHINE.	24
4.3. PREPARING FOR TRANSPORTATION.	24
4.4. COUPLING TO THE TRAILER	24
4.5. USE OF THE LIFTING BEAM (OPTION)	26
5. OPERATION	27
5.1. STARTING UP	27
5.2. EMERGENCY STOP.	27
5.3. PRODUCTION	28
5.4. HOOK UP THE FRONT LEG.	29
6. MAINTENANCE	30
6.1. MAINTENANCE DIAGRAM	31
6.2. CLEAN THE MACHINE.	32
6.3. LUBRICATION OF REAR GATE	32
6.4. BRAKE ADJUSTMENT.	33
6.5. CHECK OIL LEVEL/REPLACE OIL.	33
6.6. CHECK PLAY IN THE WHEELS	35
6.7. BANDENSPECIFICATIES	36
6.8. CHECK THE SHAFT BOLTS.	37
6.9. PARTS	37
7. DISPOSAL AS WASTE	38
8. APPENDIX	39
8.1. LOGBOOK	39

LIST OF PICTURES

FIGURE 1: OVERVIEW SA0051/SA0051B	13
FIGURE 2: OVERVIEW OF THE ELECTRICAL INSTALLATION	15
FIGURE 3: WIRELESS REMOTE CONTROL (OPTION)	17
FIGURE 4: OVERVIEW OF THE HYDRAULIC INSTALLATION	18
FIGURE 5: DETAILS OF CONVERSION FROM TRANSPORT SET-UP TO WORKING SET-UP (SA0051)	22
FIGURE 6: DETAIL OF HOOKING UP FRONT LEG	29
FIGURE 7: LUBRICATION OF REAR GATE	32
FIGURE 8: DETAIL OF BRAKE ADJUSTMENT	33
FIGURE 9: DETAILS OF FILLING OF HYDRAULIC UNIT	34
• FIGURE 10: HYDRAULIC FLUIDS TO BE USED	35
FIGURE 11: DETAILS OF SHAFT BOLT TORQUE SETTINGS	37

EC- DECLARATION OF CONFIRMITY FOR MACHINERY (COPY)

(Conform appendix II, under A, Directive 2006/42/EC)



Manufacturer: Wopa Constructiebedrijf B.V.
Adress: Rector Hulshofstraat 10
NL-7135 JV Harreveld
The Netherlands
☎: +31-(0)544 372415
E-mail: info@wopa.com
Website: www.wopa.com

Declare that:

Machine: Claw treatment box
Type number: SA0051BHL
Serial number: 046

- Complies with the provisions of the Machinery Directive 2006/42/EC, as last amended (including safety requirements of Low Voltage Directive 2014/35/EU) and the national legislation implementing this Directive.
- Where applicable also complies with the provisions of the following EC-Directives:
EMC-Directive 2014/30/EU

Following (parts of) harmonized standards are applied:

- NEN-EN-ISO 12100:2010
NEN-EN-IEC 60204-1:2018
NEN-EN-ISO 13849-1:2016
NEN-EN-ISO 13854_2019
NEN-EN-ISO 4413_2010

Technical documentation can be applied for at the above address through management department.

The Netherlands - Harreveld,
Date: __23-05-2024__

J.W.A. Wopereis
Directeur

Overview of symbols

The following symbols are used for all actions that jeopardise the safety of the user and/or technician and require caution.

	Attention!
	Hazard: High voltage!
	Hazard: High temperature!
	Tip: Offers quick insight or tips to carry out certain actions more easily and simply.

Pictograms

A number of pictograms and alerts are affixed to the installation to indicate possible risks to users, among other things.

Pictogram	Description	Location
	Type plate	On the machine frame
	- Read the user manual - Wear safety goggles when operating machine - Wear hearing protection when operating machine.	On the machine frame
	The presence of unauthorised persons within turning range of the box is strictly prohibited.	On the machine frame
	- Warning pictograms - System under pressure.	On either side of the frame
	Warning pictograms for mechanical and electrical hazards	On the machine frame
	Warning pictogram Snagging hazard for hand	On the machine frame
	Warning pictogram Never walk under the load during hoisting.	On the machine frame
	Crushing hazard	By the rear gate.
	Warning pictogram Electrical hazards.	On the machine frame
	Warning pictogram Snagging hazard for foot.	On the machine frame
	ATTENTION! Check regularly whether the pictograms and signs are still clearly recognisable and legible. Replace if this is no longer the case.	

1. Technical information

	SA0051	SA0051B	
General			
Ambient temperature during operation	- 10 to 35	- 10 to 35	°C
Noise production	< 75	< 75	dB(A)
Machine dimensions			
Length	2100	2100	mm
Width	1750	1500	mm
Height	2000	2000	mm
Maximum product dimensions			
Length	3290	2700	mm
Width	1750	1500	mm
Height	2400	2400	mm
Electrical connection			
Power supply	1 or 3 phase	1 or 3 phase	-
National voltage	230 or 400	230 or 400	V
Required fuse	8.7 or 5,9	8.7 or 5.9	A
Connected value	1.5 or 2.5	1.5 or 2.5	kVA
Hydraulic installation			
Maximum operating pressure	155	155	bar
Tank volume	14	14	litre
Type of oil	See Figure 9	See Figure 9	
Data for road transport			
Axial load	1350	-	kg
Maximum drawbar load	100	-	kg
Coupling	ISO 55 mm	-	-
Connection plug	7 of 13	-	pole
Tyre pressure	2,9	-	bar
Wheel bolt torque	110	-	Nm

* see electrical diagram

* If the box is fitted with a 230V plug, the plug must be connected to a wall-mounted socket protected by a residual current operated circuit-breaker (always according to the local regulation in effect). (30mA)

2. Description of the installation

	FUNCTION • This section gives an overview of the most important components and functions. If detailed information is available elsewhere in the manual, you are referred to the specific sections. • The design of your crush may differ from the figures below.
---	---

2.1. Description of the main components SA0051/SA0051B

	FUNCTION • The SA0051 and SA0051B were developed especially for dairy cattle and beef cattle hoof trimming. • Version SA0051 is equipped with an axle with a draw bar and is suitable for transport on public roads.
---	---

The main components of the crush are shown in the illustration below:




Figure 1: Overview SA0051/SA0051B

Main components SA0051/SA0051B:

Figure 1	Component	Description	See Section
1	Front gate	- The front gate can be set to 3 positions with the hydraulic controls: - Entirely open: the cow can exit the crush at the front. - Partially open: the cow can move its head through the front gate but not its shoulders. Stationary position. - Closed: the front gate is closed behind the animal's head.	-
2	Front leg support	The cow's front leg can be secured to the front leg support by means of a hydraulic winch so the leg can be treated.	5.4
3	Electrical connection cable	The crush must be connected to the electricity network for power supply for operation and the hydraulic power unit.	
4	Folding gate	The standard version includes a folding gate for guiding the cattle.	
5	Hydraulic rear gate	Once the cow is moved into the crush, the rear gate is placed lightly against the back of the animal.	
	Hind leg (hydraulic)	After the belt is attached round the hind leg, the leg can be lifted with the hydraulic winch so the hoof can be treated.	
6	Transport set (light bar) (SA0051)	A light bar with a license plate is attached to the crush for transport on public roads.	
	Belly strap (hydraulic)	Once the cow is moved into the crush, the belly strap is lifted hydraulically behind the front legs.	
7	Transport set (axle) (SA0051)	An axle with mudguards is attached to the crush for transport on public roads.	
8	Props	The 4 props adjust the crush to the desired height. A lift is also possible as an option.	
9	Transport set (draw bar arm) (SA0051)	A draw bar arm is attached to the crush for transport on public roads	
10	Lifting beam	If the lifting beam is fitted, the crush can be moved using a crane.	

2.2. Electrical installation

	FUNCTION • The electrical installation supplies the power for the hydraulic power unit, lighting and sockets. • See the electrical diagram in the control panel of every crush for the rest of the structure and controls of the electrical installation included in the delivery. • The placement of the control components on your installation may differ from the photo below.
	ATTENTION! • Work on the electrical installation can only be carried out by a technical expert.




Figure 2: overview of the electrical installation

The installation consists of the following components

 Figure 2	Component	Description	Section / location
-	Power supply cable	To connect the machine to the power supply.	
1	Emergency stop	The emergency stop switches off all operations.	
2	Sockets	The grinders can be connected to these.	
3	Control panel?	The control components are on the control panel.	
4	Lights	Used to light the work site.	
5	Lighting	Switches the lights on the crush on/off.	
6	Electric eye (option)	This activates the catch position of the front gates.	
-	Position switch 400V direction of rotation. (version-dependent)	- For machines where the electric motor can run on 400V, the correct direction of rotation of the 3-phase power supply must be set at each connection point. - This can be determined by trial and error. Only if the correct direction of rotation is selected will the hydraulic functions operate correctly.	

Wireless remote control (option)



	FUNCTION
	- The wireless remote control is an option. - The number of function keys (6, 8 or 10) depends on the number of machine functions to be controlled. - The assignment of the various machine functions to the function keys is set up specifically for the customer.



Figure 3: **Wireless remote control (option)**

2.3. Hydraulic installation

	FUNCTION • The hydraulic installation supplies the power for the various functions. • See the hydraulic diagram for a detailed description of the installation. • The placement of the control components on your installation may differ from the photo below.
	ATTENTION! • Work on the electrical installation can only be carried out by a technical expert. • Always ensure that the accumulator is depressurised when the installation is in operation.






Figure 4: overview of the hydraulic installation

The installation consists of the following components

Figure 4	Component	Description	Section / location
1	Right valve block	- The valves control the following functions: - Front gate; when closing, it stops in the stationary position where the head can be moved through the gate. - Rear gate; the rear gate is equipped with pressure monitoring so that the force on the animal is limited. - Belly strap - Hind leg - Step (option) - Lift (option).	
-	Left valve block (SA0051)	In addition to the functions of the right valve block, the left valve block also has a valve to move the frame onto or off the axle.	
2	Front leg valve	It operates the front leg winch.	
3	Power unit	See the type plate on the motor to connect the power supply.	
4	Accumulator	The accumulator stores hydraulic oil so that much of the hydraulic capacity is available during operation of hydraulic functions.	
5	Main valve	- The main valve shuts off the accumulator from the rest of the hydraulic installation. - This valve must be closed if the installation is not in use. The valve can be accessed via an opening in the protective cover. - The power unit cannot be switched on if the valve is closed.	
6	Oil depressurising valve	This valve is normally closed. If the hydraulic installation needs to be depressurised to implement work, open this valve slowly. The plug must be out of the socket and valve 5 must be open in order to also allow the oil to flow out of the accumulator.	
7	Valve block left (SA0051)	- The valves are used to control the following functions: - Front gate; when closing, it is stopped in the catch position in which the head can be inserted through the gate. - Tailgate; the tailgate is fitted with a pressure limiter to limit the force on the cow. - Drive axle; when operating the axle upwards, the pawl has to be raised manually. If the axle has to be lowered again in the driving position, the pawl lifts automatically. - Belly band	

Figure 4	Component	Description	Section / location
		Rear foot	

3. Safety

3.1. General

	• The guarantee will lapse and no liability will be accepted in the event of damage caused by repairs and/or modifications not authorised by the supplier. • In the event of faults please contact the supplier. • The working area around the installation must be safe. The owner of the installation must take the necessary precautionary measures in order to operate the installation safely. • Starting up the installation in an area with a risk of explosion is prohibited. • The installation has been so designed that production is safe under normal ambient conditions. • The owner of the installation must ensure that the instructions in this manual are followed in practice. • The safety features provided must not be removed. • Correct operation and safety of the system can only be guaranteed where maintenance is carried out correctly and in good time, as prescribed. • Where work is to be carried out on the installation it must be disconnected from the power supply, the power supply must be locked off and the system must be depressurised. • There is a risk of trapping when operating driven moving parts. It is the operator's responsibility to ensure that the installation is only started up when no parts of his own or other people's bodies are in the vicinity of the trapping zone. • Ensure that the weight distribution of the towed crushes is not changed. If the weight distribution between left and right sides and/or front and rear (too high or low nose load) is disturbed, this may lead to instability on the road or during use. • When operating self-propelled boxes, it is forbidden to move the box if there are persons in the driving area of the box. • It is not permitted to go under a crush raised with a lift. If there is a fault in the installation, the crush could come down.
	• Only authorised persons appointed by the owner may carry out work on the electrical installation. • Ensure by means of internal procedures and supervision that all applicable power supplies have been switched off. • The installation must not be used during cleaning, inspection, repairs or maintenance, and must be disconnected from the electrical supply by means of the plug and/or the main switch. • Welding work must not be carried out on the installation unless the cable connection to the electrical components has first been disconnected. • The power supply to the control cabinet must not be used for the connection of machinery other than the hand tools provided for.

3.2. During normal use

	• Check before commencing operations that no work is being carried out on the installation and that it is ready for use. • Unauthorised persons must not enter the operational area of the installation. It is the operator's task to check this. • Components of the hydraulic system may reach high temperatures. Contact with these components may cause injury.
---	---

3.3. Operating personnel

	• Operating personnel must be aged 18 or above. • Only authorised persons may carry out work with or on the installation. • Only work for which proper training has been received must be carried out. This applies both to maintenance activities and normal use. • The operating personnel must be familiar with all potential situations, so that rapid and effective action can be taken in an emergency. • Where a member of operational staff observes defects or risks or is not in agreement with the safety measures, this must be reported to the owner or the manager. • Safety footwear is mandatory. • Suitable work clothing is mandatory. • All employees must observe the safety instructions to avoid presenting a risk to themselves and others. Comply strictly with the operating instructions at all times.
---	--

4. Installation

	EXPLANATION Consult the technical data and the circuit diagram provided for the correct specifications.
---	---

4.1. Location

	CAUTION - The machine must be transported and installed upright. - Place the machine on a level and stable substrate - Take account of the instructions in Section 3 when carrying out any activity. Failure to follow these may lead to serious injury.
---	--

	EXPLANATION - This section describes fitting the SA0049 with a wheel set. - If you have an SA0049B (without a wheel set), only items 2, 3 and 12 apply.
--	--




Figure 5: details of conversion from transport set-up to working set-up (SA0051)

No.	What to do	Action	Result
1.	Tip the nose wheel downwards.	Ensure that the crush is resting on the nose wheel.	
2.	Connect the crush.	See 4.2,5.1	
3.	Lower the adjusting feet	- Lower the 2 front adjusting feet (Figure 5:3) by pushing them down with the foot and lock them at the desired height with the chain. - If the lift option is fitted, then first remove the folding gates (Figure 5:2) from the crush and allow the crush to rise under hydraulic pressure.	
4.	Remove the locking pin from the drawbar.	Rotate the locking pin upwards (Figure 5:4) and remove it.	
5.	Open the front gate.	Operate the valve to open the front gate.	
6.	Tip the crush back.	- Tip the crush to the rear so that the drawbar is clear of the ground. With the rear gate raised the crush will remain in that position. Check that the folding gates are still secured with the front support feet ropes. - This is not necessary with the optional lift.	
7.	Free the drawbar and the brake cables.	- Rotate the locking knob (Figure 5:6) and unlock the clamp situated in the middle of the drawbar, then slide the nose wheel of the crush off until the drawbar comes free from the crush. - The brake cables are now free of tension and can easily be unhooked at the wheel side. - Once the brake cables are loose they can be placed in the tube provided in the middle of the drawbar. Keep fingers clear of this tube to avoid danger of trapping.	
8.	Tip the crush forwards.	- Lift the rear of the crush so that it tips forwards. The drawbar now rests on its nose wheel and the ball joint connection in the box. - Where the lift option has been selected you should now remove the mudguards (see point 10), tilt the wheels (see point 13) and then allow the crush to sink hydraulically using the lift. - Disconnect the drawbar ball mounting.	
9.	Remove the drawbar.	Remove the drawbar from the crush and store it out of the way. The shaft will be held upright by the elastic cord attached to the ball mounting.	
10.	Remove the mudguards	Loosen the locking elements and lift the mudguard out of the adapter.	
11.	Remove the lighting board.	Remove the lighting board from the crush.	
12.	Lower the rear adjusting feet.	Lower the 2 rear adjusting feet (Figure 5:1) by pushing them down with the foot and lock them at the desired height with the chain.	
13.	Tip the axle.	- Lift the axle cylinder locking mechanism. - Operate the valve until the wheels are folded up.	
14.	Install the side gates.	Withdraw the side gates (Figure 5:2) from the crush and place them in the desired position.	

4.2. Connect the machine.

	CAUTION • Check that the voltage specified on the machine plate matches the mains supply. • The machine must always be connected to an earthed socket to avoid the risk of fire or electric shocks (the earth connection is coded green/yellow). • The electrical installation including the sockets must be connected in accordance with local regulations. • The power cable must always be free and nothing must be placed on top of it. • Replace the power cable immediately if it is damaged.
---	---

4.3. Preparing for transportation.

	CAUTION • Preparing for transportation is the reverse procedure to making ready for use (see 4.1). • With crushes equipped with an axle and drawbar it is essential that all locking mechanisms are correctly installed.
--	---

4.4. Coupling to the trailer

The trailer coupling head is equipped with a safety check indicator. The following refers to different positions and colour fields.



Marking	Coupling position	Handle position	Meaning
	Coupling is open	Handle is pulled up	WARNING The trailer must NOT be driven.
	Coupling is closed	Handle is in the starting position	The trailer may be driven.
	Wrong position	Handle is in the starting position	WARNING The trailer must NOT be driven.

Uncoupling.

- Pull up the ball handle and swing it forward until the pointer remains in the red field with the cross (X position).
- The trailer may not be driven after this point.
- CAUTION! Do not insert fingers into the opened trailer coupling head!
- Even a slight pressure on the ball cap can activate the locking mechanism and lead to the fingers being injured.


Coupling.

- The trailer coupling head should be in the open X position and placed on the ball of the towing vehicle after which it engages audibly.
- The pointer in the green field is now in the + position.
- After coupling, the pointer should always be used to check that the trailer coupling head is correctly locked to the ball.
- If the pointer is in the green field (+ position) then the coupling is correctly closed and there is still sufficient wear reserve.
- CAUTION! Only in this case is a secure connection made between your vehicle and the trailer and it is permitted to drive on the open road.
- Attach the breakaway cable to the ball neck and connect the plug to the vehicle's socket. Release the handbrake from its lock.
- STOP! When the pointer is in the red field (- position), the coupling is incorrectly closed and the trailer may NOT be driven under any circumstances.
There can be three causes for this.
 1. The ball on the vehicle is already very worn and does not provide the trailer coupling head with sufficient grip.
 2. The trailer coupling head itself is very worn and no longer provides sufficient grip on the ball. In this case, the trailer coupling head must be replaced.
 3. The locking mechanism of the trailer coupling head was activated, but there is no ball in the coupling. The trailer coupling head is loose on the ball and not connected. In this case, open the trailer coupling head as previously described and try again.
- CAUTION! When the pointer is in the red field and - position, the trailer coupling head is not closed. Under no circumstances should the trailer then be driven.
- The locking mechanism may be stiff due to lack of lubrication. In this case, lubricate the mechanism and try again.

General

- The maximum permissible swivel range of the trailer coupling head in relation to the vehicle axis is 25°.
- In the horizontal direction, turning angles in a range of approximately 20° are possible.
- CAUTION! If the turning ranges are exceeded, the components are overloaded and the function of the trailer coupling head is no longer guaranteed.
- The handle of the trailer coupling head indicates its permissible nose load.
- STOP! A trailer should not be driven with a negative nose load as it affects driving stability.
- A negative nose load can easily be changed by moving the load on the trailer.
- The installation, repair, adjustment and conversion work of drawbar eyes or trailer coupling heads may only be carried out by qualified garages.
- CAUTION! To ensure optimal driving and braking behaviour of the trailer, it is essential that the coupling heights of the towing vehicle and trailer match. According to DIN74058, the position of the coupling point on the trailer should be about 35mm above the point where the wheel is on the ground. To check the coupling height, the trailer and towing vehicle must be exactly horizontal and loaded to the full permissible weight.

4.5. Use of the lifting beam (option)



A lifting beam with a lifting eye is fitted to the top of the machine. This lifting eye must be used when lifting the machine. The machine then remains in balance.

The operator of the crane is responsible for responsible/safe lifting of the machine and making the environment safe.

The owner is obliged to have the lifting beam inspected annually by an EKH-certified body.

5. Operation

	CAUTION Take account of the instructions in Section 3 when carrying out any activity. Failure to follow these instructions may lead to serious injury.
---	--

5.1. Starting up

No.	What to do	Action	Result
1.	Switch on the power.	Insert the plug in the socket.	
2.	Reset the emergency stop.	Pull out the emergency stop buttons.	The control unit is now ready for use.
3.	Activate the hydraulic system.	Open the shut-off valve (Figure 4:5) at the accumulator.	
4.	Switch off the electricity	After working, always remove the power plug from the electrical outlet.	

5.2. Emergency stop.

	CAUTION - The emergency stop button must always be pressed in in the event of an emergency. - All motions will cease following operation of the emergency stop button. - In order to take the machine back into use after an emergency stop the emergency stop button must first be reset. - Before resetting the emergency stop button it must be ensured that restarting the moving parts of the machine will not lead to a hazardous situation.
---	---

- Reset the emergency stop**

No.	What to do	Action	Result
1.	Reset the emergency stop button.	Reset the emergency stop button by pulling it out or rotating it (depending on the type installed) so that it returns to its original position.	The machine is now ready for use.

5.3. Production

No.	What to do	Action	Result
1.	Check that the crush is ready for use.	See Sections 5.1.	
2.	Place the front gate ready.	Open the front gate so that the head of the animal can pass through but not its withers. When the front gate is closed hydraulically it will stop at the correct position and the handle can be released. This means that the holding position is always the same.	
3.	In order to	- Lead the cow into the crush until its head has passed through the front gate. - Close the front gate. Where a sensor is installed (option) the front gate will close automatically when the cow is in position. Attention: While working with an electric eye, the cow should walk independently into the crush. If a person walks through the eye at the front, he/she may become trapped.	
4.	Bring the rear gate into position.	- Lower the rear gate. In order to avoid the risk of damage to the front legs, ensure that the rear gate is NOT pressed up tightly against the animal.	
5.	Raise the belly belt.	Bring the belly belt up under the belly of the cow.	
6.	Process a rear hoof.	- Place the belt around the rear leg and raise the leg. Make sure that while hooking up the hook/strap, the cow's nipple is not caught in it. - Process the rear hoof. - Allow the leg to drop and release it.	
7.	Process a front hoof.	- Attach the front leg with the hook as shown in Figure 6. Operate the winch hydraulically until the leg is tight up against the block. - Process the front hoof. - Release the rope.	See 5.4
8.	Lower the belly belt.	Reverse the winch until the belly belt is on the ground.	
9.	Release the crush.	Check that all ropes and belts have been freed. - Open the front gate. - Lead the cow out of the crush.	
10.	Place the rear gate in its raised position.	Raise the rear gate.	

5.4. Hook up the front leg.

	CAUTION! • The leg can be hooked up in two ways: • With a small hook (see Figure 6:1). • With a large hook (option) (see Figure 6:2). • When hooking up with the small hook, especially with hydraulically driven winches, there is a risk of permanent injury if the front leg is pulled too tight. • When using the large hook, there is no risk of injury from over-tightening.
---	---




Figure 6: detail of hooking up front leg

6. Maintenance



CAUTION!

- Always disconnect the machine from the power supply by pulling out the plug. Where a hydraulic accumulator is present this must be depressurised.
- Test the installation on completion of maintenance work or repairs to ensure that it can be used again safely.
- Only trained technical personnel may carry out the maintenance activities described or repair work.

6.1. Maintenance diagram

The diagram below shows the maintenance activities to be carried out.

Activity	note	Daily	weekly	Every 100 animals	Annually	Every 2 years	See Section
General							
Check on panic locks and hooks.	Renew where damage is visible.						
Check ropes and chains.	Renew where damage is visible.						
Check plugs, cables, controls and connections.	Alert a competent fitter where damage is visible.						
Cleaning							
Clean the machine.							6.2
Lubrication							
Grease nipples on rear gate sliding section.	Bearing grease.						6.3
Other grease nipples.	Bearing grease.						
Hydraulic installation							
Check the oil level.	Checks must be carried out after 500 cows or where leakage occurs.						6.5
Replace oil and filter.							
Axle and wheels							
Check play in the wheels.							6.6
Check the tyre profile.	Have this inspected by a competent person.						
Check the tyre pressures.	Have this inspected by a competent person.						
Check the adjustment of the brakes.	Have this inspected by a competent person.						6.4
Drawbar							
Play in ball mounting.	Replace where minor play is evident, or see markers on the side of the ball mounting.						
Ball and coupling in crush.	Check and clean						
Check the latch.	There must always be slight tension on the latch.						
Check the shaft bolts.	Every 10,000 km.						6.8
Lifting beam (option)							
Inspection lifting beam	Have it inspected by an EKH-certified body.						

6.2. Clean the machine.


	EXPLANATION • A high-pressure cleaner may be used for cleaning. • Avoid bearings, winches and motors when cleaning with a high-pressure cleaner. Spraying in these areas may result in a sharp reduction in service life. • Avoid all electrical components when cleaning with a high-pressure cleaner. Spraying in these areas may result in risk of electric shocks and /or a sharp reduction in service life.
---	---

6.3. Lubrication of rear gate

	EXPLANATION • The rear gate is slid out with the aid of gas springs fitted to the gate. • To prevent grease entering the gas springs and causing damage, the gate must only be lubricated when it is fully drawn back.
---	--



1 2



3

Figure 7: lubrication of rear gate

No.	What to do	Action	Result
1.	Retract the rear gate.	• Attach the rear leg winch to the rear gate and tighten until the gate is fully retracted.	
2.	Grease the nipples.	• Lubricate the rear gate nipples using a grease gun.	

6.4. Brake adjustment.

	EXPLANATION • This instruction applies only where a braked axle is fitted. • Play in the brakes will increase as the brake shoes wear.
---	--




Figure 8: detail of brake adjustment

No.	What to do	Action	Result
1.	Check the play	• The play between the 2 levers (Figure 8:2) must not exceed 50 mm.	
2.	Adjust the brakes.	• Rotate the adjusting bolt (Figure 8:1) until the play is less than 50 mm.	

6.5. Check oil level/replace oil.

	EXPLANATION • Checking the oil level ensures that the necessary minimal amount of oil is present. The cylinders must be retracted for this purpose and the accumulator must be empty. The plug must be removed from the socket. • The general rule is that the oil and filter should be replaced every two years. However it is possible to use a winter oil to avoid an extended warm-up period for the oil in cold weather. Where this is used the oil will consequently be replaced twice a year. • The winter oil is not suitable for use in warmer weather as this can lead to problems.
---	--




Figure 9: details of filling of hydraulic unit

- Emptying the accumulator/gauging the oil level

No.	What to do	Action	Result
1.	Retract the cylinders.	Put the cylinders in the installation in their retracted position by operating the valves.	
2.	Prepare the controls.	- Ensure that the emergency stop buttons are pulled out. - Disconnect the power supply.	
3.	Allow the accumulator to empty.	Open the bleed valve (Figure 4:6) slowly.	The accumulator will gradually empty.
4.	Check the oil level.	The oil level must now be between the minimum and maximum levels (see instructions on "changing the oil").	

- Changing the oil

No.	What to do	Action	Result
1.	Bring the oil to the tank.	See the instruction on "emptying the accumulator/gauging the oil level".	
2.	Empty the tank.	Remove the plug from the tank and allow the oil to run out until it is empty.	
3.	Fill the installation.	Open the bleed valve (Figure 4:6) slowly.	The accumulator will gradually empty.
4.	Check the oil level.	- Open the air bleed plug (Figure 9:1). - Fill the tank via the filler cap (Figure 9:3). - Maintain the following levels: - Round tank: the middle of the sight glass (Figure 9:2). - Rectangular tank: 5 cm below the filler cap (Figure 9:4).	
5.	Check the oil level	The oil should be 2 cm below the filler cap when all cylinders are retracted.	

- The following types of oil are suitable for use in the hydraulic installation:

Leverancier	Olie
Castrol	HYSPIN AWH – M 32 / 46
Mobil	UNIVIS N 32 / 46
Q8	HANDEL 32 / 46
Q8	HELLER 32 / 46
Texaco	RANDO 32 / 46
Texaco	HYDRAULIC OIL HDZ 32 / 46
Total	EQUIVIS ZS 32 / 46
Valvoline	100 ULTRAMAX HVLP 32 / 46
Petronas	HYDRAULIC HV 32 / 46
Gulf	HARMONY HVI 32 / 46
Shell	TELLUS S2 V 32 / 46
Shell	TELLUS T 32 / 46

- Figure 10: hydraulic fluids to be used**

6.6. Check play in the wheels.

	EXPLANATION
	- This paragraph applies only to versions fitted with a wheel axle and pulling mandrel. - Raise the wheels from the ground and feel if any play is present. - If play can be detected this must be corrected by a competent person, or otherwise the bearings and seals must be replaced.

	EXPLANATION
	After the first 50 km, check that all the wheel bolts are still firmly in place. Using a torque spanner, tighten the wheel bolts see chapter 1 for the correct value.

	EXPLANATION
	- Check the physical condition of the tyres and their tread regularly. - Check the tyre pressure regularly. See chapter 1 for the correct value.

6.7. Bandenspecificaties

Variant:	B1	B2	B3	B4
1050 kg as		X	X	X
1350 kg as	X	X	X	X

Tyres:	Size:	Pressure:	LI:	Rims:	ET value:	R.dyn:
B1	185/70 R13	300 kPa	90	4.5 / 5 / 5.5 / 6 J x 13	+20 tot/to +35	286 mm
B2	175 R13 C	450 kPa	97	4.5 / 5 / 5.5 J x 13	+20 tot/to +35	295 mm
B3	175 R14 C	450 kPa	99	5 / 5.5 / 6 J x 14	+20 tot/to +35	306 mm
B4	185/75 R14 C	475 kPa	102	5 / 5.5 / 6 J x 14	+20 tot/to +35	306 mm

Minimum speed class

Symbol:	Speed:
N	140 km/h

Rolling resistance

	Stage 1*	Stage 2*
C1 Tyre	≤ 12.0 kg/t	≤ 10.5 kg/t
C2 Tyre	≤ 10.5 kg/t	≤ 9.0 kg/t

*For snow tyres, the limits shall be increased by 1kg/ton

6.8. Check the shaft bolts.

	EXPLANATION • This paragraph applies only to versions fitted with a wheel axle and pulling mandrel. • After 10,000 km or once annually the shaft bolts must be tightened with a torque wrench in accordance with the figure below.
---	---




Figure 11: Details of shaft bolt torque settings

6.9. Parts

	EXPLANATION • Consult the website at www.wopa.com for information on the available options and the parts available to order.
---	--

7. Disposal as waste

Oil and components must not be disposed of as domestic waste. When replacing components or oil or at the end of the machines service life, ensure that all materials are collected and destroyed or reused in a legal and environmentally friendly manner.



8. Appendix

8.1. Logbook

The logbook must include the following:

- The annual maintenance work
- Major replacements and any accidents
- Modifications
- Tests on emergency stop buttons and safety features

[illegible]

[illegible]